

# HOW TO INSTALL A CERAMIC VASE FOUNTAIN KIT



**Step 1:**  
Layout appropriate Matrix and Pump Canyon configuration.



**Step 2:**  
Excavate basin to required size and depth.



**Step 3:**  
Ensure Matrix & Pump Canyon fit.



**Step 4:**  
Install Underliner & Liner



**Step 5:**  
Install Pump Canyon & Matrix Boxes.



**Step 6:**  
Set Ceramic Vase in Position



**Step 7:**  
Add Pump to Pump Canyon



**Step 8:**  
Connect Plumbing from Pump to Vase



**Step 9:**  
Add Gravel



**Step 10:**  
Fill with Water



**Step 11:**  
Trim Liner and Finish Edges



**Step 12:**  
Plug in Pump and Run!